

JAYCO VENT VALVE MAINTENANCE

BEFORE PROCEEDING WITH MAINTENANCE ON THE VENT VALVE, CONSULT YOUR COMPANY'S SAFETY AND OPERATIONS MANUALS CONCERNING THE DANGERS INVOLVED WITH WORKING ON A VENT VALVE AND TANK BATTERY. **USE EXTREME CAUTION!**

OBSERVE...

- THE OPERATION OF THE VENT VALVE, IS IT HOLDING PRESSURE?
- DOES IT RELIEVE PRESSURE AS SET?

CLEAN...

- KEEP THE GASKETS AND MOVING PARTS FREE OF DIRT AND RESIDUE
- INLINE VALVES HAVE A DRAIN PLUG IN THE BODY TO EMPTY FLUID IF NECESSARY, DO SO IN
 COMPLIANCE WITH ENVIRONMENTAL REGULATIONS

INSPECT...

- THE GASKETS FOR WEAR, CRACKING AND SWELLING; REPLACE AS NEEDED
- THE ALUMINUM SEATS INSIDE THE VALVE AND PLUNGER FOR DAMAGE AND REPAIR OR REPLACE AS
 NEEDED
- SOME STACK VALVES MAY HAVE AN EXTERNAL LEVER, ENSURE LEVER HAS PROPER MOVEMENT WITH THE INTERNAL PRESSURE/VACUUM VALVE

REPAIR OR REPLACE...

- REPLACE GASKETS WITH JAYCO GASKETS SETS ONLY
- IF H2S IS PRESENT OR OTHER CHEMICALS THAT REACT WITH THE CURRENT GASKETS, REPLACE WITH VITON® GASKET SETS
- IF AMBIENT TEMPERATURE IS ABOVE 200 DEGREES F, REPLACE GASKETS WITH VITON®
- WHEN CLOSING THE CAPS ON INLINE VALVES, TIGHTEN THE TWO NUTS EVENLY FOR A GOOD SEAL

ORDER JAYCO PARTS FROM YOUR LOCAL OILFIELD SUPPLY COMPANY OR TANK MANUFACTURER

THE FOLLOWING PAGES WILL ASSIST YOUR SELECTION OF REPLACEMENT PARTS

** KEEP THE VENT VALVE CLEAN AND INSPECT ON A REGULAR BASIS **

- PAGE 1 INLINE VENT VALVE PARTS LIST FOR JAYCO
- PAGE 2 STACK VENT VALVE PARTS LIST FOR JAYCO
- PAGE 3 PRESSURE SETTINGS ON JAYCO VENT VALVES

800-654-9263 • 405-751-6903 • FAX 405-755-7940 • WWW.JAYCO.ORG

JAYCO PARTS LIST INLINE VENT VALVES



	2 9 3d	3 3 3 C BRESSURE/VAC ASSEMBLY C	3a 3b 3f 3g 3g 3g 3g 3g 3g 3g 3g 3g 3g 3g 3g 3g
	JV 101 - 2″	JV 301 - 3″	JV 500 - 4″
BODY LENGH W/O FLANGES HEIGHT	8.25″L 7″H	10″L 8″H	10.5″L 10.5″H
1. VALVE BODY - ALUMINUM			
2. VALVE BODY CAP - ALUMINUM	JV0121	JV0321A	JV0520
3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE	JV0110	JV0311	JV0510
3a. PAN HEAD SCREW - ZINC PLATED	JV0156	JV0156	JV0156
3b. INTERNAL LOCK WASHER - ZINC PLATED	JV0155	JV0155	JV0155
3c. WASHER (SMALL) - ALUMINUM	JV0148	JV0150	JV0348
3d. WASHER (LARGE) - ALUMINUM	JV0150	JV0348	JV0350
** 3e. VACUUM GASKET - BUNA N	JV0152	JV0353	JV0352
VACUUM GASKET (SOUR SERVICE) - VITON®	JV0153	JV0354	JV0553
3f. VACUUM VALVE STEM - BRASS	JV0146	JV0146	JV0446
** 3g. VACUUM SPRING - STAINLESS STEEL	JV0144	JV0144	JV0444
4. SLIP-ON FLANGE - ALUMINUM	JV0136	JV0337	JV0436
5. SLIP-ON FLANGE BOLT - ZINC PLATED	JV0181	JV0181	JV0181
6. SLIP-ON FLANGE NUT - ZINC PLATED	JV0180	JV0180	JV0180
7. DRAIN PLUG - RED PLASTIC	JV0158	JV0158	JV0158
** 8. PRESSURE O-RING GASKET - VITON [®] CURRENT VALVES	JV0141	JV0341	JV0440
PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES	JV0142	JV0343	JV0342
9. SLIP-ON FLANGE GASKET - BUNA N	JV0134	JV0335	JV0434
10. EYE BOLT - ALUMINUM	JV0126	JV0126	JV0126
11. HEX NUT - ZINC PLATED REPLACES WING NUT	JV0137	JV0137	JV0137
** 12. CAP GASKET - BUNA N	JV0125	JV0323	JV0522
CAP GASKET (SOUR SERVICE) - VITON®	JV0127	JV0325	JV0523
13. GROOVE PIN - ZINC PLATED	JV0131	JV0130	JV0130
PRESSURE WEIGHT 1.0 oz - BRONZE	JV0260B	JV0360B	JV0460B
PRESSURE WEIGHT 0.5 oz - BRONZE	JV0260A	JV0360A	JV0460A
HIGHER WEIGHT SETTINGS VISIT: WWW.JAYCO.ORG/PROD	UCTS-CATEGORY/JAY	CO-VENT-VALVE/	

IN KEEPING WITH, AND FOR THE PURPOSE OF PRODUCT IMPROVEMENT, JAYCO RESERVES THE RIGHT TO MAKE DESIGN CHANGES WITHOUT PRIOR NOTICE. ** REPAIR KIT VITON® IS A REGISTERED TRADEMARK OF DUPONT DOW ELASTOMERS BULLETIN NUMBER 1015 23

JAYCO PARTS LIST STACK VENT VALVES



11 10 2 7			
		j.	<u>3a</u>
			3b
			<u>3f</u>
			3g
6			
8			
4	. /		
5	<u>3d</u>	<u>3c/ \3a \3</u>	
	PRI	ESSURE/VACUUM VAL ASSEMBLY COMPLETE	VE
	JV 200 - 2″	JV 401 - 3″	JV 600 - 4″
1. VALVE BODY - ALUMINUM	JV 200 - 2	JV 401 - 3	JV 000 - 4
2. VALVE BODY CAP - ALUMINUM	JV0220	JV0421	JV0420
 VALVE BODY CAP - ALUMINUM PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 	JV0220 JV0110	JV0421 JV0311	JV0420 JV0510
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 	JV0110 JV0156 JV0155	JV0311 JV0156 JV0155	JV0510 JV0156 JV0155
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 	JV0110 JV0156 JV0155 JV0148	JV0311 JV0156 JV0155 JV0150	JV0510 JV0156 JV0155 JV0348
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 	JV0110 JV0156 JV0155 JV0148 JV0150	JV0311 JV0156 JV0155 JV0150 JV0348	JV0510 JV0156 JV0155 JV0348 JV0350
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181	JV0311 JV0156 JV0155 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262	JV0311 JV0156 JV0155 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141	JV0311 JV0156 JV0155 JV0350 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - BUNA N ORIGINAL VALVES 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142	JV0311 JV0156 JV0155 JV0350 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262 JV0240 JV0342
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440 JV0342 JV0342
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 10. EYE BOLT - ALUMINUM 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335 JV0325	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440 JV0342 JV0342 JV0434 JV0126
 PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 10. EYE BOLT - ALUMINUM 11. HEX NUT - ZINC PLATED REPLACES WING NUT 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126 JV0137	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335 JV0326 JV0343	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0446 JV0446 JV0440 JV0180 JV0262 JV0440 JV0342 JV0434 JV0126 JV0137
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL *** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 10. EYE BOLT - ALUMINUM 11. HEX NUT - ZINC PLATED REPLACES WING NUT 12. LEVER - ALUMINUM OPTIONAL 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126 JV0137 JV0230	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335 JV0126 JV0137 JV0431	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0446 JV0446 JV0446 JV0446 JV0436 JV0181 JV0180 JV0262 JV0440 JV0342 JV0434 JV0126 JV0137 JV0431
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 10. EYE BOLT - ALUMINUM 11. HEX NUT - ZINC PLATED REPLACES WING NUT 12. LEVER - ALUMINUM OPTIONAL 13. GROOVE PIN - ZINC PLATED 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126 JV0137 JV0230 JV0131	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0262 JV0343 JV0335 JV0126 JV0137 JV0130	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440 JV0262 JV0434 JV0126 JV0137 JV0431 JV0130
 3. PRESSURE/VACUUM VALVE ASSEMBLY <i>complete</i> 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® <i>current valves</i> PRESSURE CLIP-IN GASKET - BUNA N <i>ORIGINAL VALVES</i> 9. SLIP-ON FLANGE GASKET - BUNA N <i>ORIGINAL VALVES</i> 11. HEX NUT - ZINC PLATED <i>REPLACES WING NUT</i> 12. LEVER - ALUMINUM <i>OPTIONAL</i> 13. GROOVE PIN - ZINC PLATED PRESSURE WEIGHT 1.0 oz - BRONZE 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126 JV0137 JV0230 JV0131 JV0260B	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335 JV0126 JV0137 JV0431	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440 JV0262 JV0434 JV0126 JV0137 JV0431
 3. PRESSURE/VACUUM VALVE ASSEMBLY COMPLETE 3a. PAN HEAD SCREW - ZINC PLATED 3b. INTERNAL LOCK WASHER - ZINC PLATED 3c. WASHER (SMALL) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM 3d. WASHER (LARGE) - ALUMINUM ** 3e. VACUUM GASKET - BUNA N VACUUM GASKET (SOUR SERVICE) - VITON® 3f. VACUUM VALVE STEM - BRASS ** 3g. VACUUM SPRING - STAINLESS STEEL 4. SLIP-ON FLANGE - ALUMINUM 5. SLIP-ON FLANGE BOLT - ZINC PLATED 6. SLIP-ON FLANGE NUT - ZINC PLATED 7. CONICAL LEVER SPRING - ZING PLATED OPTIONAL ** 8. PRESSURE O-RING GASKET - VITON® CURRENT VALVES PRESSURE CLIP-IN GASKET - BUNA N ORIGINAL VALVES 9. SLIP-ON FLANGE GASKET - BUNA N 10. EYE BOLT - ALUMINUM 11. HEX NUT - ZINC PLATED REPLACES WING NUT 12. LEVER - ALUMINUM OPTIONAL 13. GROOVE PIN - ZINC PLATED 	JV0110 JV0156 JV0155 JV0148 JV0150 JV0152 JV0153 JV0146 JV0144 JV0136 JV0181 JV0180 JV0262 JV0141 JV0142 JV0134 JV0126 JV0137 JV0230 JV0131	JV0311 JV0156 JV0155 JV0150 JV0348 JV0353 JV0354 JV0146 JV0144 JV0144 JV0337 JV0181 JV0180 JV0262 JV0341 JV0343 JV0335 JV0126 JV0137 JV0431 JV0360B	JV0510 JV0156 JV0155 JV0348 JV0350 JV0352 JV0553 JV0446 JV0444 JV0444 JV0436 JV0181 JV0180 JV0262 JV0440 JV0262 JV0440 JV0342 JV0431 JV0431 JV0430

HIGHER WEIGHT SETTINGS VISIT: WWW.JAYCO.ORG/PRODUCTS-CATEGORY/JAYCO-VENT-VALVE/

IN KEEPING WITH, AND FOR THE PURPOSE OF PRODUCT IMPROVEMENT, JAYCO RESERVES THE RIGHT TO MAKE DESIGN CHANGES WITHOUT PRIOR NOTICE. ** REPAIR KIT VITON® IS A REGISTERED TRADEMARK OF DUPONT DOW ELASTOMERS BULLETIN NUMBER 1007 23



JAYCO VENT VALVES PRESSURE SETTINGS

JAYCO VENT VALVES ARE SHIPPED FROM THE FACTORY SET AT 1.3 OZ/INCH² PRESSURE FOR 2" AND 3" VALVES WHILE 4" VALVES ARE SET AT 1.5 OZ/INCH², UNLESS OTHERWISE SPECIFIED. THE VACUUM SETTING OF 0.4 OZ/INCH² IS SPRING OPERATED AND NOT AFFECTED BY CHANGING THE PRESSURE SETTING.

TO INCREASE THE PRESSURE SETTING OF THE VALVE, WEIGHTS CAN BE ADDED TO THE INTERNAL PLUNGER ASSEMBLY. FOR HIGHER PRESSURE SETTINGS THE ALUMINUM PLUNGER MUST BE REPLACED BY A BULLET PLUNGER.



SMALL INCREASE

ADD WEIGHT(S) IN 0.5 OZ/INCH² OR 1 OZ/INCH² INCREMENTS TO THE PLUNGER ASSEMBLY TO GAIN DESIRED PRESSURE SETTING. THIS IS DONE WITH BRONZE WASHERS CALLED WEIGHTS. EACH VALVE HAS A MAXIMUM AMOUNT OF WASHERS THAT CAN BE ADDED.

PICTURED 1 oz WEIGHT • FLEXIBILITY

MEDIUM INCREASE

WHEN ADDING MORE THAN 1 OZ/INCH² A CUSTOM BRONZE WEIGHT CAN BE ADDED TO THE PLUNGER ASSEMBLY TO GAIN THE DESIRED PRESSURE SETTING. I.E. ADD A 2.5 OZ/INCH² WEIGHT TO A STANDARD PLUNGER ASSEMBLY TO HAVE A PRESSURE SETTING OF 4 $OZ/INCH^2$, (1.5 + 2.5 = 4.0).



PICTURED 2.5 oz WEIGHT • ECONOMICAL



LARGE INCREASE

FOR HIGHER PRESSURE SETTINGS THE PLUNGER ASSEMBLY MUST BE SWITCHED OUT WITH A CUSTOM "BULLET PLUNGER ASSEMBLY." THESE LARGE BRONZE WEIGHTS HAVE THE VACUUM BREAKER BUILT INTO THEM. THESE ARE SOLD BY THEIR TOTAL PRESSURE SETTING AND NOT THEIR ADDITIONAL INCREASE LIKE THE WEIGHTS.

PICTURED 16 oz BULLET PLUNGER

FOR MORE INFORMATION AND PART NUMBERS PLEASE VISIT THE VENT VALVE PAGE AT JAYCO. ORG. THE PRESSURE SETTING TAB HAS INFORMATION ON MAXIMUM AMOUNT OF WEIGHTS THAT CAN BE ADDED TO EACH VALVE AND WHEN A "BULLET PLUNGER" MUST BE USED.

REMEMBER THAT INCREASING THE PRESSURE SETTING ON THE VENT VALVE WILL DELAY THE PRESSURE RELIEF. MAKE SURE THAT THE CHANGES MADE WILL WORK WITHIN THE CONFINES OF THE INSTALLATION. PLEASE CALL IF YOU HAVE QUESTIONS ABOUT THIS DOCUMENT.